REMINGTON®

# Rechargeable
All-In-One Groomer
PG3000




## Use and Care Guide

**Register Your New Product Today!**

By registering your new Remington® product, you will receive special offers.
**Register online at: RemingtonProducts.com**

# IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions should always be observed, including the following.

**READ ALL INSTRUCTIONS BEFORE USING THIS APPLIANCE.**

## DANGER

**To reduce the risk of electric shock:**

- Do not reach for an appliance that has fallen into water. Unplug it immediately.
- Do not use while bathing or in the shower.
- Do not place or drop into water or other liquid.
- Do not place or store this appliance where it can fall or be pulled into a tub or sink.
- Except when charging, always unplug this appliance from the electrical outlet immediately after using.
- Unplug this appliance before cleaning it.

## WARNING

**To reduce the risk of burns, fire, electric shock or injury to persons:**

- This appliance is for household use only.
- An appliance should never be left unattended when it's plugged in, except when charging a rechargeable appliance.
- Close supervision is necessary when this appliance is used by, on, or near children or persons with special needs or certain disabilities.
- Use this appliance only for its intended use as described in this manual.
- Do not use attachments not recommended by Spectrum Brands, Inc.
- Keep the cord away from heated surfaces.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or if it has been dropped into water.
- Never drop or insert any object into any of the appliance's openings.
- Do not use outdoors or operate where aerosol (spray) products are being used, or where oxygen is being administered.
- Always store this appliance and cord in a moisture-free area. Do not store it in temperatures below -4°F (-20°C) or exceeding 140°F (60°C).
- Make sure the cord is disconnected from the groomer when storing.
- Do not use this appliance with a damaged or broken cutter unit, as injury may occur. Always make sure blades are aligned properly.
- Always attach plug to appliance, then adapter to outlet. To disconnect, turn all controls to OFF, then remove adapter from outlet, then detach power cord from the clipper for storage.
- Do not use an extension cord or a voltage converter with this appliance.
- Do not wrap the cord around the appliance.
- The power unit is intended to be correctly oriented in a vertical or floor mount position.

# SAVE THESE INSTRUCTIONS

## Product Features




1. Full-Size Trimmer
2. Groomer Body
3. On/Off Switch
4. Detail Trimmer
5. Nose, Ear, and Eyebrow Trimmer
6. 10-Length Adjustable Comb
7. Beard and Stubble Combs: 3mm, 6mm, 9mm
8. USB charging cable (not shown)
9. Pouch (not shown)

## Before Using

Before using your Personal Groomer for the first time, charge the unit for 16 to 18 hours for optimal performance:

1. Ensure the product is turned off.
2. Connect the USB charging cable to the product. Plug into a USB port on a computer or a USB plug adaptor in an electrical outlet. Charge time is 24+ hours.
   - Run time is up to 70 minutes.

**NOTE: The LED will remain illuminated the entire time the unit is plugged in, regardless of the battery charge level.**

## How to Use

### What Attachments to Use

| | Full Size Trimmer | Nose & Ear Trimmer | Hair Length Combs | Detail Trimmer |
|---|---|---|---|---|
| Beard | x | | x | |
| Beard line | x | | | x |
| Ear | | x | | |
| Eyebrow | | x | x | |
| Mustache | x | | x | |
| Nape of neck | x | | | |
| Nose | | x | | |
| Sideburns | x | | x | x |
| Head Hair | | | x | |

**Note:** this product is for cordless use only.

- Switch the product on by sliding the On/Off switch upward.

**TO ATTACH AND REMOVE THE TRIMMING ATTACHMENTS**

**Note:** Always ensure the groomer is switched off before changing any attachments.

- To attach, place the desired trimming head on top of the groomer and rotate clockwise to lock into place.
- To remove, rotate the trimmer head counter-clockwise until it unlocks and then lift off the groomer.

## How to Use, continued

**ATTACHING AND REMOVING FIXED GUIDE COMBS ON THE WIDE TRIMMER BLADE**

**To Attach**

- With the trimmer blade facing away from you, hook front of comb onto blade teeth and pivot back end down until it clicks into position.

**To Remove**

- With the trimmer blade facing away from you, carefully push the tab on the back of the guide comb upwards and away from the trimmer blade.

**ATTACHING AND REMOVING ADJUSTABLE COMB ON THE WIDE TRIMMER BLADE**

- To attach line up the comb rails and slot on the groomer until firmly secured. Pressing the adjustment button on the back of the comb will alter the cutting length increment, this is indicated on the comb.
- To remove press and hold the adjustment button and push the comb up and off the groomer.

**BEFORE YOU BEGIN**

- Comb facial hair with a fine comb before you start trimming.
- Hairs should be dry and without any waxes or lotions before using the groomer.

**TO THIN AND TAPER THE BEARD/MOUSTACHE**

- Attach the wide trimmer blade.
- Place either the adjustable comb or a fixed comb on the trimmer blade, select the desired length and switch on.
- Start trimming under the chin, following the jawbone line. Work toward the ear and upper beard line using an upward motion.

**TO TRIM EDGE OF BEARD OR MOUSTACHE**

- Attach the trimmer blade.
- Hold the groomer with the cutting blade facing you.
- Start with edge of beard/moustache line, and with the cutting blades resting lightly against your skin, use slow movements to create a beard/moustache line.

**TO TRIM SIDEBURNS**

- Hold the groomer with the cutting blade facing you.
- Select the desired length on the adjustable comb or select the desired guide combs.
- Use light pressure and well-controlled movements to trim hair.

**TRIMMING THE NAPE OF YOUR NECK**

- Attach the trimmer blade.
- Use your fingers to lift the hair at the base of your head up off the neck. Your index finger should be covering the roots of the hairs you are lifting to prevent accidental removal by trimmer.
- Using your other hand, hold the trimmer to the base of your neck with the cutting unit facing up, and move the trimmer up the length of the neck until it touches your finger covering the hair roots at the base of your head.
- Be sure to move the unit slowly when performing this operation and to keep the hair roots at the base of your head out of the way of the trimmer.

**TO REMOVE HAIR FROM NOSE AND EAR**

- Attach the nose, ear, eyebrow attachment.
- Insert the groomer's cutting unit gently into the nostril or ear.
- Gently move the groomer in and out of the nostril or ear.
- Avoid inserting the cutting unit more than 6mm into your nostril.

**TO REMOVE HAIR FROM EYEBROWS**

- Attach the nose, ear, eyebrow attachment.
- Gently guide the cutting unit to stray, unwanted hairs along the eyebrow line or protruding from the eyebrow itself.
- To remove the hairs completely lower onto the skin and move over desired area.
- Use short, well-controlled movements.

**USING THE DETAIL ATTACHMENT**

- Hold the groomer with the cutting blade facing you.
- Rest cutting blades lightly on the skin.
- Use for more precise trimming of stray hairs or smaller areas.

**TIPS FOR BEST RESULTS**

- Comb your hair in the direction that it grows so that the hairs are at their maximum height and facing in the same direction.
- Since all hairs do not grow in the same direction, you may want to try different trimming positions (i.e. upwards, downwards or across) for better results.

## Cleaning, Care, and Maintenance

**NOTE:** Always clean trimmer attachments regularly to ensure maximum performance and a proper operating life.

**DO NOT RINSE TRIMMER HANDLE.**

**CLEANING ATTACHMENTS WITH WATER**

1. Remove attachment.
2. Rinse ONLY the attachment under warm running water. Do NOT use hot water as this might cause damage.

**OILING BLADES AND CAUTIONS**

- Rinsing attachments under water (above) requires lubricating the cutting blades 1x monthly. Using only light-grade oils (e.g. sewing machine oil), simply spread 1–2 drops lightly over cutters. Wipe away all excess.

## Battery

### Battery Removal

When your rechargeable groomer reaches the end of its useful life, the batteries must be removed and recycled or disposed of properly in accordance with your local and state requirements.

## Warranty

### Limited Three-Year Warranty

Empower Brands, LLC warrants this product to the original purchaser against any defects that are due to faulty material or workmanship for a three-year period from the original date of consumer purchase. This warranty does not include damage to the product resulting from accident or misuse. If the product should become defective within the warranty period, we will replace it free of charge. Keep your sales receipt and call 800-736-4648 in the U.S. or Canada or contact us at: contactus@remingtonproducts.com for warranty information.

**KEEP ORIGINAL SALES RECEIPT AS PROOF OF PURCHASE FOR WARRANTY PURPOSES.**
This warranty does not cover products damaged by the following:

- Accident, misuse, abuse or alteration of the product
- Servicing by unauthorized persons
- Use with unauthorized accessories
- Connecting it to incorrect current and voltage
- Any other conditions beyond our control

No responsibility, obligations, or liability is assumed for the installation or maintenance of this product.

**EMPOWER BRANDS, LLC SHALL NOT BE RESPONSIBLE FOR ANY INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT. ALL IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF FITNESS AND MERCHANTABILITY, ARE LIMITED IN DURATION TO FIVE YEARS FROM DATE OF ORIGINAL PURCHASE.**

This warranty gives you specific legal rights and you may also have other rights which vary from state to state or province to province. Some states do not allow the exclusion or limitation of incidental, special or consequential damages.

**This warranty shall not be valid where it is contrary to U.S. and other applicable laws, or where the warranty would be prohibited under any economic sanctions, export control laws, embargos, or other restrictive trade measures enforced by the United States or other applicable jurisdictions. This includes, without limitation, any warranty claims implicating parties from, or otherwise located in, Cuba, Iran, North Korea, Syria and the disputed Crimea region.**

### Empower Brands, LLC Money-back Offer

If within 30 days after you have purchased your Remington® branded product from an authorized source, you are not satisfied and would like a refund, return it with the sales receipt indicating purchase price and date of purchase to the retailer from whom it was purchased. Empower Brands, LLC will reimburse all retailers who accept the product within 30 days from the date of purchase. If you have any questions concerning the money-back guarantee, please call 800-736-4648 in the U.S. or Canada.

**Remington Guarantees Satisfaction After 30 Days!**

**Remington 60-Day Money Back Guarantee***
If within 60 days after purchasing any Remington® product, you are not completely satisfied and would like a refund, keep your receipt and contact us at contactus@remingtonproducts.com or call 800-736-4648 in the U.S. or Canada.**
*Applies to U.S. and Canadian customers' returns only.
**Terms and conditions apply.

1. Refund will be in the form of a check issued in U.S. Dollars and will include applicable taxes, if any, paid by customer.
2. Please allow 4 – 6 weeks to receive your refund by check.

Please do not throw this product away with normal household waste.
If possible, take it to an official collection point in your area that recycles this type of product. Thank you for considering the environment.

5VDC input **Type: PG03B**

**Questions or comments:** Call 800-736-4648 in the U.S. or visit **RemingtonProducts.com.**

Dist. by: Empower Brands, LLC, Middleton, WI 53562
® Registered Trademark and ™ Trademark of Empower Brands, LLC.
© 2023 Empower Brands, LLC. All rights reserved. 5/23 29817

**Made in China**

**T22-7003062-A**