



BENDER wireless headphones with Bluetooth V5.1

TQBWH-0031W


Content



1 x Charging case



1 x Wireless headphones



1 x Charging cable
USB-A / USB-C

System requirements and headphone connection

- Bluetooth adapter in case of computer use.
- It is recommended to use Android 10 or later versions.

Phone connection


- Open the case and take the headset.
- On your mobile phone, open the settings and look for the ‘Bluetooth’ tab. You will then see the Bluetooth devices that are available, search for your headset such as TQBWH-0031W.
- Pair them by clicking on the device name. You may need to enter a passcode to pair the first time. Try ‘0000’ or ‘1234’ and you will be able to use them on your phone.

Computer connection

- Open the case and take the headset.
- On your computer, open the settings. Go to ‘Devices’ and search for ‘Bluetooth and other devices’. You will then see the available Bluetooth devices, search for your headset such as TQBWH-0031W.
- Pair them by clicking on the device name and clicking ‘Connect’. You may need to enter a passcode the first time to pair, try ‘0000’ or ‘1234’ and you will be able to use your headset on your computer.


Touch buttons on Android and iOS

For Android



1. **Press once** to Pause and Play.
2. **Press twice** to skip to the next playback.
3. **Press three** times to repeat current playback.
4. **Press and hold** to open Google Assistant.

For iOS



1. **Press once** to Pause and Play.
2. **Press twice** to skip to the next playback.
3. **Press three** times to repeat current playback.
4. **Press and hold** to open Siri Assistant.

Warranty information

Since 1 January 2022, TooQ offers a 3-year warranty from the time of purchase, so it will always keep the purchase ticket or invoice containing the date of purchase. The distributor or retailer from whom you purchased the product will attend to your claim and offer technical service while the warranty is in force.

Out of warranty

The warranty does not cover damage or defects caused to the external enclosure due to:

- Not following the user manual.
- Modifications or alterations of any kind.
- High and low temperatures, humidity or contact with liquids.
- Worn and scratches caused by daily use.
- Use the product with any other device which is not the one indicated for its use. The warranty does not cover damage or defects caused to the hard drive by improper use of the hard drive or the external enclosure.

FAQ

You can consult the frequently asked questions from our website www.tooq.com on the product link. Products may be subject to variations due to stock changes, product improvements or printing errors. In case of doubt, please contact us.

Find out about all our news!

Follow us on social media

©2024 by TooQ Technology, S.L.
All Rights Reserved.
tooq.com